

To program your Sky HD (Latest Version) remote to your television:

1. On any SKY channel Press the 'RED BUTTON' (in 'sky' mode)
2. Press 'GREEN BUTTON' for 'sky active'
3. Scroll down to 'customer support' and press 'SELECT'
4. Scroll down to 'set up your remote control' and press 'SELECT'
5. From here you will be guided step by step through the set up process of programming your sky HD remote to your television.